

Bespoke Supremo Floors

MAINTAINACE INSTRUCTIONS



WAX OILED SHOULD APPLIED AS A LAST APPLICATION BEFORE USING YOUR NEW FLOOR

For final protection an extra coat of Hard Wax Oil clear such as Osmo 3032-Satin or Osmo 3065 semi matt, or Bona Wax is needed*.

CLEANING AND MAINTENANCE

We do recommend Osmo Wax cleaner, instructions as per below.

Wax Cleaner is designed to renovate our bespoke wax floors that has been finished with Hard Wax Oil. The Wax Cleaner will clean stubborn stains and leave the surface re-freshed with natural hard waxes.

PREPARATION

Surface should be clean and dry. Use Hoover or vacuum, Dust or damp mop before applying Liquid Wax Cleaner. Heavy use and commercial areas should be regularly cleaned with Osmo Wash and Care and water prior to applying Liquid Wax Cleaner.

APPLICATION

Manually- Apply approximately 1 cup per m² of Liquid Wax Cleaner with a lint free cloth or nylon pad such as Mirka Mirlonpads for more aggressive cleaning. Using Liquid Wax Cleaner regularly will ensure the surface will be more resistant to dirt and wear and tear.

COVERAGE: 40-50m² for 500ml

DRYING: 30-40 minutes

FOR WHITE BESPOKE: Bianco, Pure - Wax cleaner (3087)

FOR OTHER: Wax cleaner (3029)

LONG-TERM MAINTENANCE

PROPERLY MAINTAINED:

Vacuum regularly. Remove sticky spills and clean regularly with a cloth or mop dampened with OSMO Wash & Care diluted in water. Don't slosh water onto the floor. Just as with any floor finish, high-traffic areas will show wear over time. Prompt attention restores the finish. Clean thoroughly. Dry. Then moisten fine steel wool or a white Scotchbrite pad with OSMO Liquid Wax Cleaner. Rub onto the surface.

*** Always try on small parts or off cut prior to applying whole area. Bona Wax should not apply on Snow White/Bianco and Pure.**